

# Pre-installation Manual



PlateWriter™ 8000


NewsWriter™ XL



# Pre-installation Manual

---

**PlateWriter™ 8000**  
**NewsWriter™ XL**



T11320

**Edition AA, September 2012**  
**This book has part No. 10066402**

This manual is published by: **GLUNZ & JENSEN A/S**  
Selandia Park 1  
DK-4100 Ringsted  
Denmark  
Phone: +45 57 68 81 81  
E-mail: [gjhq@glunz-jensen.com](mailto:gjhq@glunz-jensen.com)  
Internet: [www.glunz-jensen.com](http://www.glunz-jensen.com)

© 2012 Glunz & Jensen A/S. All rights reserved.

# Table of contents

<b>Part 1: Introduction</b>	<b>1-1</b>
About this manual	1-1
Intended use of this manual	1-1
Reservations	1-1
Important	1-1
Unintended use of the equipment.	1-1
Installation	1-1
Notes, cautions, and warnings !	1-2
<b>Part 2: When the crate arrive</b>	<b>2-1</b>
Storing the crate.	2-1
Crate dimensions and weight.	2-1
Checking the crate for damage.	2-2
Handling the crate	2-2
Lifting the crate	2-2
Transporting the crate.	2-3
Available doorway width for transport.	2-3
<b>Part 3: Site requirements</b>	<b>3-1</b>
General requirements	3-1
Environmental requirements	3-1
Cleaning facilities.	3-1
Space requirements	3-2
PlateWriter / NewsWriter dimensions	3-2
Free space around the PlateWriter / NewsWriter	3-3
RIP workstation	3-4
Location	3-4
Network connection	3-4
Power supply	3-5
Main power connection.	3-5
Power outlet requirements.	3-6
Power consumption	3-6
Power cables	3-7
<b>Part 4: Pre-installation checklist</b>	<b>4-1</b>



# Part 1: Introduction

## About this manual

### Intended use of this manual

- This manual describes how to prepare the installation site for the installation of the PlateWriter™ 8000 / NewsWriter™ XL System. The procedures described in this manual require a reasonable level of technical skill and access to the proper tools.

### Reservations

- This manual was written and illustrated using the best possible information available at the time of publication.
- Any differences between this manual and the equipment reflect improvements introduced after the publication of the manual.
- Changes, technical inaccuracies and typographical errors will be corrected in subsequent editions.
- As a part of our policy of continuous improvement, we reserve the right to alter design and specifications without further notice.

## Important

### Unintended use of the equipment

Glunz & Jensen A/S do not take any responsibility for any damage or accidents caused by unintended use of the equipment:

- As the equipment is certified by accredited test laboratory (UL International Demko A/S) it is absolutely prohibited to make any modifications, electrical nor mechanical, of the equipment. If however this prohibition is disregarded, Glunz & Jensen's warranty will no longer apply and the certification labels for UL, C-UL, and CE certification of the equipment shall be removed as the certification will no longer apply to the equipment.

### Installation




- Never install the equipment in explosive environments.
- It is the responsibility of the owner and operator/s of the equipment, that the installation is made in accordance with local regulations, and by engineers authorized to carry out electrical installations.
- Installation must be performed only by service technicians who are trained in installing the equipment.
- The manufacturer cannot be held responsible for any damage caused by incorrect installation of this equipment.

## Notes, cautions, and warnings !

Throughout the manual notes, cautions, and warnings are written in bold like the example below:



**Always replace a fuse with one of the same size and rating as the old one.**

Symbol	Meaning	Explanation
	<b>Note</b>	The operator should observe and/or act according to the information in order to obtain the best possible function of the equipment.
	<b>Caution</b>	The operator must observe and/or act according to the information in order to avoid any mechanical or electrical damage to the equipment.
	<b>Warning</b>	The operator must observe and/or act according to the information in order to avoid any personal injury.



## Part 2: When the crate arrive


### Storing the crate

The crate containing the PlateWriter™ 8000 / NewsWriter™ XL System will usually arrive some time before the arrival of the Service Technician. In such a case you should prepare an appropriate place indoors to store the crate.

### Crate dimensions and weight

Below are the dimensions and weight of the crate included with the delivery:

	L x W x H	Weight
<b>PlateWriter / NewsWriter,</b> crated ( $\pm$ 5%)	2369 x 2018 x 1706 mm (93.3 x 79.5 x 67.2")	approx. 750 kg (1653 lb)



T32270

## Checking the crate for damage


Check if the crate is damaged at the time of delivery. Take note of the damage before you allow the service technician to unpack the crate. Provide a detailed description or take a photograph of the damage.

**i** Note that there are shock and tilt watch indicators on the crate. Their serial numbers are listed in the box label of the crate too and therefore have to be identical.

**i** Report any damage to the crate to the transport company.

## Handling the crate

The icons on the crate indicate how to handle them during transport and storage:



Ensure that the side indicated by the arrows is always up



Handle the crate with care.



Never expose the crate to water, or place it in a high-humidity area.



Do not stack the crates.

T31691




## Lifting the crate

To lift the crate, at least a fork-lift truck or four persons and a hand-powered pallet mover are required.

## Transporting the crate

### Available doorway width for transport

Depending on the width of the door(s) through which the PlateWriter / NewsWriter System has to be transported to the installation site, the Service Technician may have to perform the actions described in the table below:

If width of the door is ...	Then...
more than 2050 mm (80.7")	No action is required as the crated System can be transported with a fork lift immediately to the installation site.
less than 2050 mm (80.7") but more than 1900 mm (74.8")	The Service Technician has to unpack the System and mount the wheels according to the descriptions in the Hardware Installation manual. The System can then be transported on its wheels to the installation site.
more than 1900 mm (74.8") but PlateWriter / NewsWriter has to be transported on the other floor	The Service Technician has to unpack the System, dismount the input, exit table, and printer and remove the finishing unit according to the descriptions in the Hardware Installation manual. The System can then be turned upside down and transported with four persons holding the four ends of the sliding frame. The imaging unit can be transported with five or more persons.   <b>This procedure and reassembling takes 5 extra installation hours.</b>
less than 1900 mm (74.8") but more than 1400 mm (55.1")	The Service Technician has to unpack the System, dismount the input and exit table and remove the finishing unit with its sliding frame according to the descriptions in the Hardware Installation manual. The System can then be transported with a fork-lift or hand-powered pallet mover and four persons to the installation site.   <b>This procedure and reassembling takes 2 extra installation hours.</b>
less than 1400 mm (55.1")	The Service Technician has to unpack the System and dismount it according to the descriptions in the Hardware Installation manual. Then the parts have to be transported to the installation site separately.   <b>This procedure and reassembling takes 5 extra installation hours.</b>



**When it is needed to unpack the PlateWriter / NewsWriter System before transport to the installation site, it is of a vital importance to secure the dry place for unpacking.**



# Part 3: Site requirements

## General requirements

### Environmental requirements

Provide a heating and ventilating system capable of maintaining room temperature between 20 and 24°C (68 and 75°F) and relative humidity between 40 and 80%.

For heat emission see “Power consumption” on the page 3-6.

### Cleaning facilities


We recommend that you have easy access to a sink and a water tap with hot water for cleaning purposes.

The minimum recommended size of the sink is 100 x 40 cm (39.4 x 15.8").


## Space requirements

### PlateWriter / NewsWriter dimensions

#### Side view



#### Top view



T11321


## Free space around the PlateWriter / NewsWriter

Decide where the unit shall be placed and make sure that the free space around it makes operation and servicing possible.

Be aware of the following:

- **Liquid Dot** cartridges need to be replaced on left side of the unit.
- Access to cables is required at the both sides of the unit.
- Plates are loaded onto the input table from the front right of the unit.
- After imaging the plate must be placed on the finishing unit's transport belts from the lower front of the unit.
- After finishing, the plate must be removed from the finishing unit's exit tray at the lower back of the unit.

The recommended minimum free space around the machine is specified in the illustration below:



T32271

## RIP workstation

### Location

The RIP workstation must be placed within 3 m (9 ft) from the imaging unit as they need to be connected using the enclosed USB-cable.



To avoid any harmful communication interference between the RIP workstation and the imaging unit, it is recommended not to use a USB-cable longer than 3 m (9 ft).

### Network connection

If the RIP workstation is going to be connected to a local network (LAN) make sure to provide a network connection nearby.



## Power supply




Electrical installation must conform to local rules and regulations.

### Main power connection

The PlateWriter / NewsWriter System requires three main power connections, one for the PlateWriter / NewsWriter itself, one for the finishing unit and print bed (the print bed is powered from the finishing unit), and one for the RIP workstation.

The PlateWriter / NewsWriter main power inlet is located at the right side of the equipment and finishing unit main power inlet is located at the left side of the equipment (see illustration below).



T32272

## Power outlet requirements

If not already present, main power outlets should be installed in the room where the unit will be situated. Max. distance to the machine 2 m (6 ft.).



**Due to high leakage current, earth connection is essential before connecting power supply.**



**The units are Class 1 appliances and must be connected to earthed mains socket outlets.**



**These units require a short circuit protection device in the building installation as specified below.**



**Specification on the unit's name plate is the actual input current and will thus not be identical to below mentioned.**

	Unit	Supply/fuse
EUR	Printer unit	Single Phase, 1W + N + PE, 230V, 50 - 60 Hz Fuse: Max. 16A, type D01, gL/gG, interrupting capacity 50kA
	Finishing unit	Single Phase, 1W + N + PE, 230V, 50 - 60 Hz Fuse: Max. 16A, type D01, gL/gG, interrupting capacity 50kA
	RIP workstation	Single Phase, 1W + N + PE, 230V, 50 - 60 Hz Fuse: Max. 16A, type D01, gL/gG, interrupting capacity 50kA
USA	Printer unit	Single Phase, 1W + N + PE, 115V, 50 - 60 Hz Fuse: Max. 20A, class G or CC branch circuit, interrupting capacity 100kA
	Finishing unit	Single Phase, 2W + PE, 230V, 50 - 60 Hz Fuse: Max. 20A, class G or CC branch circuit, interrupting capacity 100kA
	RIP workstation	Single Phase, 1W + N + PE, 115V, 50 - 60 Hz Fuse: Max. 20A, class G or CC branch circuit, interrupting capacity 100kA
All	Voltage tolerance	± 10%

## Power consumption

	Mode	Imaging unit	Finishing unit
EUR/ USA	Stand-by:	approx. 3,4 BTU/hour	approx. 170 BTU/hour
	Sleep:	approx. 55 BTU/hour	-
	Operation:	approx. 240 BTU/hour	approx. 7100 BTU/hour


## Power cables

**i** The equipment is delivered with the power cables required for the installation (USA only, outside USA these must be ordered separately).

If, for some reason, you decide to use cables others than the supplied, make sure that they conform to the directions given below.


**h** If you are replacing a plug, be aware that the yellow/green conductor may only be connected to a terminal marked  $\oplus$  or  $\perp$ .

### Printer + RIP workstation (USA)




1. Appliance coupler (IEC 60320)
2. Plug type NEMA 5-15P
3. Cable min. 3 x 18 AWG, type SJT or harder service

### Printer + RIP workstation (rest of world, upon order only)




1. Appliance coupler (IEC 60320)
2. Plug type may vary
3. Cable min. 3 x 18 AWG, type SJT or harder service

**Finishing unit (USA)**

T11136

1. Appliance coupler 16A (IEC 60320)
2. Plug type NEMA L6-15P, 230V AC, 15A
3. Cable min. 3 x 18 AWG, type SJT or harder service

**Finishing unit (rest of world)**

T11137

**i** A connector plug only included with the maintenance kit when the country of installation is specified upon order.

- 29759, Cable, maintenance kit, Europe
- 29760, Cable, maintenance kit, UK
- 29761, Cable, maintenance kit, Denmark
- 29762, Cable, maintenance kit, Italy
- 29763, Cable, maintenance kit, Switzerland

**i** When deciding what type of cable to use, take into account the mechanical resistance (operator may step onto cable).  
 The conductors in the power supply cable should be of copper.  
 Provide for additional cable protection, e.g., cable covers, if cable is exposed to heavier transport such as fork-lift trucks etc.



**3. Ventilation and ink storage****YES NO**

- |  |                          |                          |
|--|--------------------------|--------------------------|
| A. Is air condition/ventilation system capable of maintaining room temperature between 20 and 24°C (68 and 75°F) and relative humidity between 40 and 80%? | <input type="checkbox"/> | <input type="checkbox"/> |
| B. Is capacity of air condition/ventilation adequate with regard to BTU as specified on page 3-6?  | <input type="checkbox"/> | <input type="checkbox"/> |
| C. Is there a proper storage facility for ink cartridges?  | <input type="checkbox"/> | <input type="checkbox"/> |

**4. Disposition of the various supplies and equipment on the installation site:**

T31695