Pre-installation Manual



HDX NewsSpeed

Pre-installation Manual

HDX NewsSpeed



T11397

Edition AA, November 2014
This manual has part No 10076649

This manual is published by: **GLUNZ & JENSEN A/S**
Selandia Park 1
DK-4100 Ringsted
Denmark
Phone:+45 57 68 81 81
E-mail: gjhq@glunz-jensen.com
Internet: www.glunz-jensen.com

Copyright © 2014 by GLUNZ & JENSEN A/S.

Part 0: Introduction

Reservations

- This manual was written and illustrated using the best possible information available at the time of publication.
- Any differences between this manual and the equipment reflect improvements introduced after the publication of the manual.
- Changes, technical inaccuracies and typographic errors will be corrected in subsequent editions.
- As a part of our policy of continuous improvement, we reserve the right to alter design and specifications without further notice.

Pre-installation instructions

The instructions in this Pre-installation Manual allow the customer and the Service Technician to prepare the installation of the plate processor.

Only qualified Service Technicians are allowed to unpack and install the equipment.

When preparing the installation site please take into consideration that this equipment is for restricted access locations only!

Please download the Service and User's Manuals from Glunz & Jensen A/S home page www.glunz-jensen.com before the installation of the processor.

Notes, Cautions and Warnings

Throughout the manual warnings, cautions, and notes are written in bold like the example below:

Electrical installation must conform to local regulations and guidelines.

Symbol	Meaning	Explanation
	Note	The operator should observe and/or act according to the information in order to obtain the best possible function of the equipment.
	Caution	The operator must observe and/or act according to the information in order to avoid any mechanical or electrical damage to the equipment.
	Warning	The operator must observe and/or act according to the information in order to avoid any personal injury.

Table of contents

Part 0: Introduction 0-3
Reservations 0-3
Pre-installation instructions 0-3
Notes, Cautions and Warnings 0-3
Table of contents 0-4

Part 1: Transportation 1-1
When the processor arrives 1-1
Storing the processor before installation 1-1
The crate 1-1
Dimensions and weight 1-1
Checking the crate for damage 1-2
Handling the crate 1-2
Transporting the processor 1-3
Lifting the crate 1-3
Available width for transport 1-4

Part 2: Installation requirements 2-1
Cleaning facilities 2-1
Space requirements 2-1
Free space around the machine 2-1
Water supply and drains 2-2
Water supply 2-2
Drains 2-3
Environmental requirements 2-3
Electrical requirements 2-4
Main power connection 2-4
Main power outlet 2-4
Power cable 2-4
Electrical specifications 2-5
Installation requirements for power supply 2-5
Fuses 2-5
Power consumption 2-5

Part 3: Pre-installation check list 3-1

Part 1: Transportation

When the processor arrives

Storing the processor before installation

The crated processor will usually be delivered some time before the arrival of the Service Technician. In which case you should prepare an appropriate place indoors to store the crated processor.

The crate

Dimensions and weight



	85
Width (W)	250 cm (98.4")
Length (L)	151.6 cm (59.7")
Height (H)	149.7 cm (58.9")
Weight, crated (+/- 5%)	725 kg (1598 lb)
Weight, without crate	465 kg (1025 lb)

Preheat section	85
Width (W)	151 cm (59.4")
Length (L)	118 cm (46.4")
Height (H)	75 cm (29.5")
Weight, crated (+/- 5%)	245 kg (540.1 lb)
Weight, without crate	170 kg (374.8 lb)

Checking the crate for damage

Check if the crate is damaged at the time of delivery. Take note of the damage before you allow the Service Technician to unpack the processor. Provide a detailed description or take a photograph of the damage.

Note that there are shock and tilt watch indicators on the crate. Their serial numbers are listed in the box label of the crate too and therefore have to be identical.

Report any damage to the crate to the transport company.

Handling the crate

The icons on the crate indicate how to handle the crate during transport and storage:

Ensure that the side indicated

Handle the crate with care.

Never expose the crate to water, or place it in a high-humidity area.

T31691

Transporting the processor

Lifting the crate

To lift the crate, at least a forklift truck or two persons and a hand powered pallet mover are required.

Please note that you can only insert the forks of the forklift truck or pallet mover from the side as illustrated below.

The processor is very heavy equipment. 2 - 4 people are needed for removing the processor from the pallet.



Available width for transport

Depending on the width of the door(s) through which the processor has to be transported to the installation site, the Service Technician may have to perform the actions described in the table below:

	If width of door is ...	Then
More than	155 cm (61")	No action is required as the crated processor can be transported with a fork lift immediately to the installation site.
Less than	155 cm (61")	The Service Technician has to unpack the processor according to the descriptions in the Installation manual. The processor can then be transported to the installation site.
but more than	125 cm (49")	
Less than	125 cm (49")	Arrange for adequate accessibility for transporting the processor to the installation site.

Part 2: Installation requirements

Cleaning facilities

It is essential to have easy access to a sink and a water tap with hot water where rollers, guides, and brushes can be washed.

	Minimum recommended size of the sink
85	150 x 40 cm (60 x 16")

Space requirements

Free space around the machine

Decide where the processor will be placed and make sure that the free space around the machine makes servicing possible.
The recommended minimum free space around the machine is specified in the illustration below:

For CTP On-line processors, the space requirements at the processor front must be decided separately.



T31685

Water supply and drains



Prepare the installation site for water supply and drain connections according to the illustration above. Please also refer to the processor dimensions described earlier in this document.

Water supply

Water supply must be equipped with a DIN 1988-approved return valve.

A water tap should be installed next to the installation site of the machine. Max. distance to the water tap should be 5 m (16.4 ft). The tap must be able to accept a reinforced hose minimum 15 mm (19/32") inner diameter. This hose is not included with the machine.
Another possibility is to provide the machine with tempered water through a thermostatically controlled mixing valve.

The water supply must be capable of supplying a minimum of 20 litres/min. (5 US gal./min.) at a pressure of no less than 2.75 bar (40 psi), and fitted with a check valve.

Drains

All drain hoses must have a positive fall from the processor to the drain.

Never lead drain hoses from the developer section into a drain, as most developer solutions are strong pollutants. It is also illegal to empty these types of chemicals into the public sewer system.

Under all circumstances local regulations applying to the treatment of (chemical) waste must be followed strictly.

Environmental requirements

Provide a heating and ventilating system capable of maintaining room temperature between 15 and 25°C (59 and 77°F) and relative humidity on max. 80%.

The ventilating system must be capable of renewing the air around the processor effectively. The best solution will be a hood with a Ø100-120 mm exhaust hose covering the exit of the processor with a capacity of removing min. 300 m^3/h. Alternatively an exhaust system removing the air from the room must have a capacity of min. 800 m^3/h. In both cases fresh air should be provided at floor level through light tight ventilation openings.
Be aware that the airflow must pass from the setter and across the processor - *never* the opposite way around.

Electrical requirements

Electrical installation must conform to local regulations and guidelines.

Main power connection

The main power connection is made in the processor's field-wiring box located on the left side of the processor as shown in the illustration below.



The control panel can be placed on either the left or the right side of the processor dependent on customer preferences.

Main power outlet

Provide a main power outlet close to the installation site. The table on the next page indicates the applicable power supply types and to which processor models they apply.

Power cable

The cable for the main power connection is not delivered with the processor. The table on the next side also shows recommended power supply cables.

When deciding what type of cable to use, please take into account the chemical resistance (chemicals may leak onto cable) and the mechanical resistance (operator may step onto cable).
The conductors in the power supply cable should be of copper.
Provide for additional cable protection, e.g., cable covers, if cable is exposed to heavier transport such as fork-lift trucks etc.

The processor is Class 1 equipment. Therefore, the processor must be connected to earth to avoid electrical shocks.
Please be aware of double pole/neutral fusing.

Electrical specifications

Installation requirements for power supply

Specifications on the equipment's name plate is the actual input current and will thus not be identical to below mentioned.

	Supply/fuse	Recommended cable type
EUR	3W + N + PE, 400 VAC 3 x 20 A, 50/60 Hz	Min. 5 x 2.5 mm^2 type H07RNF
US	2W + PE, 230 VAC 2 x 30 A, 50/60 Hz	Min. 3 x 10 AWG type SJO
	3W + PE, 230 VAC 3 x 30 A, 50/60 Hz	Min. 4 x 10 AWG type SJO
JAP	2W + PE, 200 VAC 2 x 25 A, 50/60 Hz.	Min. 3 x 12 AWG type SJO
	3W + PE, 200 VAC 3 x 25 A, 50/60 Hz	Min. 4 x 12 AWG type SJO

Power cord must be in accordance with local regulations.

Fuses

The fuses must have a breaking capacity of min. 100kA.
If using automatic circuit breakers make sure that they are Type D.

Power consumption

	Max. power consumption
EUR/ US	230/400 VAC operation: 4,500 Watt / 15,400 BTU/hour
	Stand-by: approx. 1,600 Watt / 5,460 BTU/hour
JAP	200 VAC operation: 4,500 Watt / 15,400 BTU/hour
	Stand-by: approx. 1,600 Watt / 5,460 BTU/hour
All	Voltage tolerance ± 10%

Part 3: Pre-installation check list

Please ask the customer to answer the following questions in order to ensure a trouble-free installation of the processor:

1. Delivery of the crate and transport to the installation site

	YES	NO
A. Is there a place indoor where the packing box can be stored temporarily?	❑	❑
B. Is there a hand-powered pallet mover, a fork-lift truck or any other lifting device available?	❑	❑
C. Can the crate be transported directly to the installation site? *See minimum width specifications on page 1-4.*	❑	❑
D. Is it sufficient to unpack the processor before it is transported to the installation site? *See minimum width specifications on page 1-4.*	❑	❑
E. Are there other factors (stairs, elevators, corners, obstacles, etc.) which should be taken into account when transporting the crate or processor?	❑	❑

If so, explain: .....

.....

.....

.....

2. Power supply

A. Make a note of the present supply specifications:

No. of Phases ..... Voltage ..... V Fused by ..... Amps
Neutral Wire? ..... Earth Wire? ..... Frequency ..... Hz

	YES	NO
B. Has a connection box been provided to connect the processor to the mains?	❑	❑
C. Is the customer aware that he/she should provide (or order) all supplies (cables, fuses, etc.) necessary to connect the processor to the mains?	❑	❑
D. Is there a house electrician available?	❑	❑
E. Are there any known problems in the building where the processor will be installed?	❑	❑

If so, explain: .....

.....

.....

.....

3. Water supply and drain

	YES	NO
A. Capacity of air condition/ventilation adequate with regard to BTU as specified on page 2-5?	❑	❑
B. Can a hose ¾" BSP be connected to the water supply tap?	❑	❑
C. Is there a large sink (with hot water) for cleaning the equipment?	❑	❑
D. Will the processor be connected to a local waste treatment system?	❑	❑
E. Is the tap water temperature adjustable? (If recommended by plate supplier).	❑	❑
F. Is the supply water pressure min. 2.75 bar (40 psi)?	❑	❑
G. Availability of warm water for cleaning of the processor?	❑	❑

4. Need for accessories

A. Remark the input height of the Rinse Gum Unit. Is there a need for leg extenders?	❑	❑

5. Disposition of the various supplies and equipment on the installation site:

T31695