


# MPA QUICK-GUIDE



(MENU)

STATISTICS  
FUNCTIONS  
ALARMS  
SETUP

PLATES  
AREA  
HISTORY

MANUAL REPLENISH  
MANUAL START  
TIMER



CONTROL PANEL  
PLATE SIZES  
INFORMATION  
AUTO TIMER  
CLOCK  
MONITOR  
SERVICE

LEFT KEY \*  
DISPLAY \*\*  
DISPLAY LIGHT  
DISPLAY CONTRAST  
SOUND  
BLACK OUT  
EDIT LOCK

S1 33.0x 44.0cm  
..  
S8

(processor type)  
MPA XX.XX.XX X  
ABSOLUTE VALUES

PLATES  
AREA  
HOURS



AUTO

XX-XX-XX XX:XX




Section CNV  
Section DEV  
Section WASH  
Section RINSE  
Section FIN  
Section DRY  
Section TRANS  
Section PROC  
Section MMI  
(Section Setter)

= Edit lock




= Service lock



# MPA QUICK-GUIDE



**TURNING OFF**



SYMBOLS	
	PROCESSOR MAIN POWER
	STAND-BY KEY
	SCROLL
	ADJUST
	MANUAL START KEY
	MANUAL REPL KEY
	"POWER ON" LAMP
	INITIAL "POWER ON"
	ALARM/WAIT LAMP
	BIB ALARM
	COUNT-DOWN

