Important:

The cleaning unit should only be shut down completely for holidays or for maintenance and/or servicing purposes. Release all roller snap bearings if the unit is switched off for more than one day!

<i>X</i> ¹⁾ <i>X</i> ²⁾	X ²)		~ 1 min.
	V 2/		
	V 21		
X ²⁾	V 2)		<i>-</i> .
	V 2)		~ 5 min.
	Λ-′		~ 5 min.
		Х	~ 5 min.
X ¹⁾			~ 10 min.
X ²⁾	X ²⁾		~ 30 min.
X 3)			~ 10 min.
Х			~ 15 min.
		Х	~ 5 min.
Every year or 250 hours		~ 30 min.	
Every 2 years or 500 hours		~ 2 hours	
Every 4 years or 1,000 hours			~ 3 hours
	X ²⁾ X ³⁾ X Eve	X ¹⁾ X ²⁾ X ³⁾ X Every year or 250 he Every 2 years or 500 he	X1) X2) X2) X3) X Every year or 250 hours Every 2 years or 500 hours

¹⁾ Replace gum bottle with half-full bottle of water. Disposal of used gum and rinse water should be handled according to local laws and regulations.

²⁾ Use sponge or soft dustfree cloth and water. Do not use any abrasive material or detergents.

³⁾ Use longhandled bottle brush to clean inside of spraybar. Use toothbrush to clean clogged spraybar holes.

⁴⁾ See the instruction of Preventive Maintenance Kit Minor.

⁵⁾ See the instruction of Preventive Maintenance Kit Medium.

⁶⁾ See the instruction of Preventive Maintenance Kit Major.