

# PlateWriter 2000 & 2400 Golden Rules Of Maintenance

Current maintenance scheme	Follow up (Date/Name)							
TASK	WHEN	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday
<i>Check &amp; refill finisher container</i>	Daily							
<i>Perform printer nozzle check*</i>	Weekly							
<i>Gum rinse with warm water for 10 minutes (program #4!)</i>	Weekly							
<i>Check/top up distilled water reservoir</i>	Weekly							
<i>Empty/refill finisher container</i>	Weekly							
<i>Clean input &amp; exit tables (with a clean damp cloth)</i>	Weekly							
<i>Clean flushing pad and head cap and apply service fluid to head cap seal**</i>	Monthly							
<i>Remove and clean gum rollers, 2 rubber plus polyurethane roller, use warm water</i>	Monthly							
<i>Clean finishing unit front/rear belts (with a clean damp cloth)</i>	Monthly							
<i>Wipe down exterior covers of the PlateWriter (with a clean damp cloth)</i>	Monthly							
<p><b>Important!</b> ALWAYS leave mains power ON at printer!</p> <p>*Perform nozzle check from the printer control panel or from the printer driver at the PC workstation. See below:            Select: Printing Preferences &gt; Utility &gt; Nozzle check &gt; Print</p> <p>**Refer to video clip placed on the desktop of the RIP computer</p>								