

PlateWriter 8000

Maintenance Chart

Current maintenance scheme	Follow up (Date/Name)							
TASK	WHEN	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday
<i>Check and refill finisher container</i>	Daily							
<i>Perform printer nozzle check*</i>	Weekly							
<i>Gum rinse with warm water for 13 minutes (program #7!)</i>	Weekly							
<i>Check/top up distilled water reservoir</i>	Weekly							
<i>Empty/refill finisher container</i>	Weekly							
<i>Clean input and exit tables (with a clean damp cloth)</i>	Weekly							
<i>Printer maintenance**</i>	Weekly							
<i>Drain, clean with warm water and refill wash section (Systems with the backside wash)</i>	Monthly							
<i>Remove and clean gum rollers, 2 rubber plus polyurethane roller, use warm water</i>	Monthly							
<i>Remove and clean wash rollers, 1 rubber and 1 scrub roller, respectively wash guide, use warm water</i>	Monthly							
<i>Clean finishing unit front/rear belts (with a clean damp cloth)</i>	Monthly							
<i>Wipe down exterior covers (with a clean damp cloth)</i>	Monthly							

* Perform nozzle check from the printer control panel or from the printer driver at the PC workstation. See below:

Select: Start > Printers and Faxes > PW8000 > Printing Preferences > Utility > Nozzle check > Print

** Refer to the video clip placed on the desktop of the RIP computer